

Anti Acne Tonic

L014-65.1-1211

Claims: Deep-cleansing and exfoliation to remove impurities and refine the skin
Dries and calms acne prone skin
dermosoft® decalact liquid is effective against *Propionibact. Acnes*

Phase	Ingredient	INCI	Supplier	%
A	Deionised Water	Aqua		76.75
	tri-Natriumcitrat-Dihydrat	Sodium Citrate	Merck	1.00
B	symbio®solv XC	Caprylyl/Capryl Wheat Bran/Straw Glycosides, Aqua, Fusel Wheat Bran/Straw Glycosides, Polyglyceryl-5 Oleate, Sodium Cocoyl Glutamate, Glyceryl Caprylate	Dr.Straetmans	1.80
	Perf. Black Currant Nat. P0250385	Parfum	Frey & Lau	0.25
	dermosoft® OMP	Methylpropanediol; Caprylyl Glycol; Phenylpropanol	Dr.Straetmans	2.00
	dermofeel® TEC eco	Triethyl Citrate	Dr.Straetmans	5.00
	dermosoft® decalact liquid	Sodium Caproyl/Lauroyl Lactylate, Triethyl Citrate	Dr.Straetmans	1.00
	Ethanol (86%)	Alcohol denat.	Merck	10.00
C	Lara Care A200	Galactoarabinan	Larex	0.20
	Alpaflor ® Plantago AO	Glycerin, Water, Plantago Lanceolata Leaf Extract	Pentapharm	2.00
	Citric Acid (sol 20%)	Citric Acid	Merck	q. s.
	Sodium Hydroxide (sol. 10%)	Sodium Hydroxide	Merck	q. s.
				100.00

Manufacturing Procedure:

1. Mix phase A and pre-dissolve phase B separately.
2. Add phase A to phase B while stirring. Add phase C.
3. Adjust pH value with phase D if necessary.

Specification Values:

Appearance: clear light brown solution.
pH value: 4.5– 5.0.

Stability: More than 3 months stable at 20 °C, 40 °C and 4 °C.

Microbiological Stability: Proven.

Disclaimer:

The information contained herein is meant to demonstrate how our products can be used. The given data are suggestions without any guarantee aimed to support customers' development. As production conditions at our customers' facilities are beyond our control we refuse to accept any liability involved in the use of our products. Please observe possible third party patent rights.